## HRI Lab #7, SP2024 525.786: Human Robotics Interaction

## Introduction:

In this lab we will explore interfacing various types of motion tracking tools. These tools, in combination with the bioinstrumentation inputs you've used previously, can be used for natural and intuitive Human Robotic Interaction. The tools that we'll be using include the following devices:

- Inertial measurement Unit (3-axis, 6 Degrees of Freedom) on the Myo
- Kinect (20 Degrees of Freedom, Whole Body)

## Setup the MiniVIE environment

```
thisPath = cd;
cd('C:\GitHub\MiniVIE');
MiniVIE.configurePath;

[MiniVIE.m] Configured MiniVIE path at: C:\GitHub\minivie

cd(thisPath);
```

## Part 1: Inertial Measurement Unit on the Myo

Operating Principle: the Myo armband contains an Angular rate sensor, accelerometer, and magnetometer to resolve orientation. These sensors can be used to track motion of the arm in addition to the EMG signals

Before running the code below, be sure to start MyoUdp.exe in the MiniVIE/+Inputs folder

It might be more straightforward to run this in the Command Window (select, then hit F9)

```
% Setup the Myo Armband in matlab
hMyo = Inputs.MyoUdp.getInstance();

[MyoUdp] Calling constructor

hMyo.initialize()
```

```
hMyo.initialize()

[UserConfig.m] Calling constructor with config file C:\GitHub\minivie\user_config.xml
[UserConfig.m] myoUdpRate=200
[UserConfig.m] myoUdpPort1=10001
[UserConfig.m] myoUdpPort2=10002

Loaded pnet Version 2.0.5 2003-09-16 Copyright (C) Peter Rydesäter, Sweden, et al. , 1998 - 2003
[PnetClass] Opened pnet socket #0 at local port: 10001; Default destination: port 45001 @ 127.0.0.1
[PnetClass] Opened pnet socket #1 at local port: 10002; Default destination: port 45001 @ 127.0.0.1
[MyoUdp] UDP Data Stream 1-8 NOT Detected
[MyoUdp] UDP Data Stream 9-16 NOT Detected
ans = 0

pause(1)
```

```
pause(1)

% Ensure data is streaming
myoData = hMyo.getData();
```

```
if isempty(hMyo.Orientation)
    error('Setup Failed. MyoUdp Running?');
end

% Setup figure to show orientation
figure(1);
clf
daspect([1 1 1])
view(-170,15)

% Plot reference triad
PlotUtils.triad(eye(4),0.5)
```

ans = 10.0009

```
% Plot 'moving' triad
myoTriadHandle = PlotUtils.triad(eye(4),2);
StartStopForm([])
while StartStopForm()
    drawnow
    hMyo.getData(); % update stream receive
    Rxyz = hMyo.getEulerAngles; % Get roll pitch yaw
    disp(Rxyz)
    Rmat = LinAlg.makeRotationMtx(Rxyz); % create rotation matrix
    transMat = [Rmat [0; 0; 0]; 0 0 0 1];
    set(myoTriadHandle,'Matrix', transMat);
end
```

Warning: The JavaFrame figure property will be removed in a future release. For more information see UI Alternatives for MATLAB Apps on mathworks.com.

0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0

0 0


0 0

0 0

0 0

0 0

0



#### hMyo.close()

[MyoUdp] Deleting Udp comms object
[PnetClass.m] Closed pnet socket #0 at local port: 10001
[PnetClass.m] Closed pnet socket #1 at local port: 10002

#### cleanup;

Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses. Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.

```
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses. Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses. Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses. Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses. Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses. Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses. Loaded pnet Version 2.0.5 2003-09-16 Copyright (C) Peter Rydesäter, Sweden, et al., 1998 - 2003
Warning: instrfindall will be removed in a future release. There is no simple replacement for this.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
Warning: Objects of 'onCleanup' class exist. Cannot clear this class or any of its superclasses.
cleanup
_____
```

#### Questions:

1. What is the 'global' position of the myo armband?

The global position is [0 0 0] with a orientation of [0 0 0]

1. What is its local coordinate frame?

The position of the local coordinate frame is the same as the global, but the orientation moves with the orientation of the myoband

1. What processing would you do to use the myo armband as a sensor to control the elbow flexion angle of a robotic device?

You would have to map the flexion of the elbow to the myoband sensor input for the angle of movement in reference to the global frame so that the orientation of the myoband maps to the orientation of the end effector on the elbow

## **Use the Myo Orientation Sensors to Plot Arm Position**

Edit the code below to show (in a streaming fashion) the real-time orientation and position of the forearm.

It might be more straightforward to run this in the Command Window (select, then hit F9)

```
hMyo = Inputs.MyoUdp.getInstance();
```

```
hMyo.initialize()
pause(1)
% Ensure data is streaming
myoData = hMyo.getData();
if isempty(hMyo.Orientation)
    error('Setup Failed. MyoUdp Running?');
end
% Can you create a real time plot of your hand's position in space using
% the real-time orientation matrix from the Myo? assume the distance from
% Myo to hand is 25 cm.
myoOrigin = [0, 0, 0];
handPosStart = [0.25, 0, 0]; % in meters
figHandle = figure(1);
clf
daspect([1 1 1])
view(-170,15)
StartStopForm([])
while StartStopForm()
    hMyo.getData();
    Rxyz = hMyo.getEulerAngles;
    Rmat = LinAlg.makeRotationMtx(Rxyz);
    disp(Rmat)
    handPos = handPosStart * Rmat;
    plot3([0, handPos(1)], [0, handPos(2)], [0, handPos(3)], '.-');
    set(gca, 'XLim', [-0.25 0.25], 'YLim', [-0.25 0.25], 'ZLim', [-0.25 0.25]);
    xlabel('x'); ylabel('y'); zlabel('z');
    drawnow;
end
hMyo.close()
cleanup;
```

#### Part 2: Kinect

Open "SDK Browser for Kinect" (search in Windows Start Menu)

Run the following examples:


- 1. Audio Basics
- 2. Depth Basics
- 3. Face Tracking Basics

#### 4. Skeletal Basics

# Copy and paste window screenshots from each:

#### 1. Audio Basic

#### Audio Basics



Beam Angle: 26 deg, Beam Angle Confidence: 1.00

### 2. Depth Basic




# 3. Face Tracking Basic

FPS = 29.98 Time = 361660472


Screenshot

#### Face Basics



PS = 30.03 Time = 360997367

### 4. Skeletal Basic



FPS = 29.99 Time = 165669508

#### Questions:

• What advantage do microphone arrays have over traditional microphones / speech input devices?

It allows you to estimate the location of the noise with triangulation and it can better filter out noise.

• At what range is the face tracking effective? How might this be used as a robot controller?

#### It works at approximately 1-3 yards from the kinnect.

• What kind of motions and postures does the skeletal model capture? When does it break down?

The skeletal model captures the spine/core, upper leg, arm and hand position such as wether the fist is clenched, but not individual finger movements.

### **Kinect sampling from MATLAB**

derived from: https://www.mathworks.com/help/imaq/examples/using-the-kinect-r-for-windows-r-from-image-acquisition-toolbox-tm.html

required MATLAB Support Package for Kinect: https://www.mathworks.com/hardware-support/kinect-windows.html

It might be more straightforward to run this in the Command Window (select, then hit F9)


```
utilpath =
'C:\ProgramData\MATLAB\SupportPackages\R2019b\toolbox\imaq\supportpackages\kinectrun
time\kinectforwindowsruntimeexamples';
addpath(utilpath);
% The Kinect for Windows Sensor shows up as two separate devices in IMAQHWINFO.
hwInfo = imaqhwinfo('kinect')
hwInfo.DeviceInfo(1)
hwInfo.DeviceInfo(2)
% Create the VIDEOINPUT objects for the two streams
colorVid = videoinput('kinect',1)
depthVid = videoinput('kinect',2)
% Set the triggering mode to 'manual'
triggerconfig([colorVid depthVid], 'manual');
colorVid.FramesPerTrigger = 100;
depthVid.FramesPerTrigger = 100;
% Start the color and depth device. This begins acquisition, but does not
% start logging of acquired data.
start([colorVid depthVid]);
% Trigger the devices to start logging of data.
trigger([colorVid depthVid]);
% Retrieve the acquired data
[colorFrameData,colorTimeData,colorMetaData] = getdata(colorVid);
[depthFrameData,depthTimeData,depthMetaData] = getdata(depthVid);
```

```
% Stop the devices
stop([colorVid depthVid]);

% display one of the frames
figure(1);
subplot(2, 1, 1);
imagesc(colorFrameData(:, :, :, 50)); axis equal tight;
subplot(2, 1, 2);
imagesc(depthFrameData(:, :, :, 50)); axis equal tight;
```

Copy and the screenshots of your RGB and depth maps:





## Skeletal tracking

Grab a frame including a person's body (i.e., "skeleton" in Kinect terms)

```
depthSrc = getselectedsource(depthVid)
depthSrc =
  Display Summary for Video Source Object:
     General Settings:
       Parent = [1x1 videoinput]
       Selected = on
       SourceName = Kinect V2 Depth Source
       Tag = [0x0 string]
       Type = videosource
     Device Specific Properties:
       EnableBodyTracking = off
% Turn on skeletal tracking.
depthSrc.EnableBodyTracking = 'on';
% Acquire 100 frames with tracking turned on.
% Remember to have a person in person in front of the
% Kinect for Windows to see valid tracking data.
colorVid.FramesPerTrigger = 100;
depthVid.FramesPerTrigger = 100;
start([colorVid depthVid]);
trigger([colorVid depthVid]);
```

# % View skeletal data from depth metadata metaDataDepth

[frameDataColor] = getdata(colorVid);

% Retrieve the frames and check if any Skeletons are tracked

[frameDataDepth, timeDataDepth, metaDataDepth] = getdata(depthVid);

metaDataDepth = 100×1 struct

Fields AbsTime BodyIndexFrame BodyTrackingID ColorJointIndices [2025,4,5,17,6,35... 424×512 double [0,0,0,0,0,0]25×2×6 double 2 [2025,4,5,17,6,35... 424×512 double [0,0,0,0,0,0]25×2×6 double 3 25×2×6 double [2025,4,5,17,6,35... 424×512 double [0,0,0,0,0,0]4 [2025,4,5,17,6,35... 424×512 double [7205800000000000... 25×2×6 double 5 25×2×6 double [2025,4,5,17,6,35... 424×512 double [7205800000000000... 6 [2025,4,5,17,6,35... 424×512 double [7205800000000000... 25×2×6 double

Fields	AbsTime	BodyIndexFrame	BodyTrackingID	ColorJointIndices
7	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
8	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
9	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
10	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
11	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
12	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
13	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
14	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
15	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
16	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
17	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
18	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
19	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
20	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
21	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
22	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
23	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
24	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
25	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
26	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
27	[2025,4,5,17,6,35	424×512 double	[720580000000000	25×2×6 double
28	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
29	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
30	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
31	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
32	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
33	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
34	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
35	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
36	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
37	[2025,4,5,17,6,36	424×512 double	[7205800000000000	25×2×6 double
38	[2025,4,5,17,6,36	424×512 double	[7205800000000000	25×2×6 double
39	-		-	
	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double

Fields	AbsTime	BodyIndexFrame	BodyTrackingID	ColorJointIndices
40	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
41	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
42	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
43	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
44	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
45	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
46	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
17	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
48	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
49	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
50	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
51	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
52	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
53	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
54	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
55	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
56	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
57	[2025,4,5,17,6,36	424×512 double	[720580000000000	25×2×6 double
58	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
59	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
60	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
61	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
62	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
63	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
64	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
65	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
66	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
67	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
68	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
69	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
70	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
71	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
72	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double

73 74	[2025,4,5,17,6,37	424×512 double		
7.1		12 1 O 12 double	[720580000000000	25×2×6 double
7-4	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
75	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
76	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
77	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
78	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
79	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
80	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
81	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
82	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
83	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
84	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
85	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
86	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
87	[2025,4,5,17,6,37	424×512 double	[720580000000000	25×2×6 double
88	[2025,4,5,17,6,38	424×512 double	[720580000000000	25×2×6 double
89	[2025,4,5,17,6,38	424×512 double	[720580000000000	25×2×6 double
90	[2025,4,5,17,6,38	424×512 double	[720580000000000	25×2×6 double
91	[2025,4,5,17,6,38	424×512 double	[720580000000000	25×2×6 double
92	[2025,4,5,17,6,38	424×512 double	[720580000000000	25×2×6 double
93	[2025,4,5,17,6,38	424×512 double	[720580000000000	25×2×6 double
94	[2025,4,5,17,6,38	424×512 double	[720580000000000	25×2×6 double
95	[2025,4,5,17,6,38	424×512 double	[720580000000000	25×2×6 double
96	[2025,4,5,17,6,38	424×512 double	[720580000000000	25×2×6 double
97	[2025,4,5,17,6,38	424×512 double	[720580000000000	25×2×6 double
98	[2025,4,5,17,6,38	424×512 double	[7205800000000000	25×2×6 double
99	[2025,4,5,17,6,38	424×512 double	[720580000000000	25×2×6 double
100	[2025,4,5,17,6,38	424×512 double	[720580000000000	25×2×6 double


% Check for tracked skeletons from depth metadata anyBodiesTracked = any(metaDataDepth(95).IsBodyTracked ~= 0)

anyBodiesTracked = logical
1


```
% See which skeletons were tracked.
trackedBodies = find(metaDataDepth(95).IsBodyTracked)
trackedBodies = 1
jointCoordinates = metaDataDepth(95).JointPositions(:, :, trackedBodies)
jointCoordinates = 25 \times 3
   0.2430
         -0.7548
                  1.4857
   0.2547 -0.5556 1.5198
   0.2647 -0.3579 1.5445
   0.2651 -0.2669 1.5464
   0.0936 -0.4471 1.5462
   0.0542 -0.6110 1.4932
   0.0575 -0.7436 1.3959
   0.0466 -0.7704 1.3789
          -0.4343 1.4651
   0.4159
   0.4413 -0.5948 1.3940
% Skeleton's joint indices with respect to the color image
jointIndices = metaDataDepth(95).ColorJointIndices(:, :, trackedBodies)
jointIndices = 25 \times 2
10<sup>3</sup> ×
          1.1019
   1.1765
   1.1792 0.9451
   1.1819 0.7987
   1.1816 0.7342
   1.0613 0.8617
   1.0368 0.9933
   1.0454 1.1294
   1.0380 1.1582
   1.3074 0.8692
   1.3460 1.0121
% Pull out the 95th color frame
image = frameDataColor(:, :, :, 95);
% Find number of Skeletons tracked
nBodies = length(trackedBodies);
```

Now plot the skeleton over the RGB image

```
[10 11];
                          [11 12]; % Left Leg
                          [12 24];
                          [12 25];
                          [21 5]; % Spine
                          [5 6];
                          [6 7];
                                  % Left Hand
                          [7 8];
                          [8 22];
                          [8 23];
                          [1 17];
                          [17 18];
                          [18 19]; % Right Hand
                          [19 20];
                          [1 13];
                          [13 14];
                          [14 15];
                          [15 16];
                        1;
% Marker colors for up to 6 bodies.
colors = ['b';'r';'g';'c';'y';'m'];
% Display the RGB image.
imshow(image);
% Overlay the skeleton on this RGB frame.
for i = 1:24
     for body = 1:nBodies
         X1 = [jointIndices(SkeletonConnectionMap(i,1),1,body)
jointIndices(SkeletonConnectionMap(i,2),1,body)];
         Y1 = [jointIndices(SkeletonConnectionMap(i,1),2,body)
jointIndices(SkeletonConnectionMap(i,2),2,body)];
         line(X1,Y1, 'LineWidth', 1.5, 'LineStyle', '-', 'Marker', '+', 'Color',
colors(body));
     end
    hold on;
 end
 hold off;
```



Copy and paste a screenshot overlaid with the extracted skeleton:



# Tasks/Questions:

• Did the skeleton model accurately capture your body geometry?

Fairly accurately, but it's a little off. The right arm skeleton was not centered on the arm and the neck was off to the side, but the core and one arm was fairly close.

• How would you estimate the elbow angle from the skeletal model?

You could estimate it by taking the angle between the upper arm and lower arm lines.

# **Submitting This Lab**

Export this \*.mlx file as Lab7\_##\_<LastName1>\_<LastName2>\_<LastName3>\_<LastName4>.pdf (## should be your computer number) and email to Lauren.Diaz@jhuapl.edu